HF-1000 ROTARY HAND PUMP INSTRUCTION MANUAL

Before using the device, carefully read the manual. Keep the manual in a safe and accessible place, so you can easily refer to it whenever necessary.



SAFETY PRECAUTIONS

- Do not transfer chemicals, solvents and water.
- Stay away from (and do not use) fire when operating the device.
- Do not cause shock to device's main body.
- Do not go away from the device until you have finished using it.
- Keep the device away from children.
- Do not disassemble, repair or upgrade the device on your own.
- Refer to the permitted liquids list.

PERMITTED LIQUIDS

- Light oil, diesel oil, kerosene
- Gasoline
- Spindle oil

USAGE INSTRUCTIONS

- Θ Insert the suction pipe into the drum can. The pipe should reach the bottom of the can. Fasten adapter's wing screw to fix pump's position.
- ② Rotate the handle clockwise to deliver the fluid

If the pump does not seem to work properly after long time of not using it \cdots

you are ready to use the pump. If, however, the device is rusted, it is no longer usable. and pull some oil into the suction pipe. Rotate the handle few times to lubricate the device. Now There are two possibilities: the pump is dry inside or became rusted. Turn the pump upside down

